



Joseph Lstiburek 6



Buildings Get Wet From The Outside Buildings Get Wet From The Inside Buildings Start Out Wet Wet Happens


Point Number 1 Buildings Must Be Designed To Dry





Lstiburek


Building Science Corporation


Joseph Lstiburek 7































































































































































































































If You Need To Run A Hygrothermal Model To Figure Out If Your Wall Works You Have The Wrong Design



Building Science Corporation

Joseph Lstiburek 99

