

Buildings Get Wet From The Outside Buildings Get Wet From The Inside Buildings Start Out Wet Wet Happens

Building Science Corporation

Joseph Lstiburek 2

Buildings Must Be Designed To Dry

Building Science Corporation

Joseph Lstiburek 3

Buildings Can Dry To The Outside Buildings Can Dry To The Inside Buildings Can Dry To Both Sides

Building Science Corporation


2<sup>nd</sup> Law of Thermodynamics


Building Science Corporation


Joseph Lstiburek 5

Heat Flow Is From Warm To Cold Moisture Flow Is From Warm To Cold Moisture Flow Is From More To Less Air Flow Is From A Higher Pressure to a Lower Pressure Gravity Acts Down

Building Science Corporation








Building Science Corporation








































































Beer Screen?

Building Science Corporation

Joseph Lstibutek 36














If You Need To Run A Hygrothermal Model To Figure Out If Your Wall Works You Have The Wrong Design


Building Science Corporation


Joseph Lstiburek 43


Water Control Layer Air Control Layer Vapor Control Layer Thermal Control Layer


Building Science Corporation








































































































































































































































































































































Air Barrier Metrics


Material 0.02 l/(s-m2)@75 Pa Assembly 0.20 l/(s-m2)@75 Pa Enclosure 2.00 l/(s-m2)@75 Pa

Building Science Corporation

Joseph Lstiburek 181







46 of 53

