6th Annual North American Passive House Conference - October 28-29 **THE PERFECT ENCLOSURE APPROACH – A RETROFIT CASE STUDY** Alex Lukachko, Building Science Corporation, Somerville, MA

History of Control Functions


- Older Buildings – One layer does
 - everything
- Newer Building


Building Science.com

- Separate layers,
 - ... separate functions



No. 2






What is a high performance enclosure?


- · One which provides high levels of control
- · Poor continuity limits performance
- Poor continuity causes most problems too:


www.BuildingScience.com


- E.g. air leakage condensation
- Rain leakage
- Surface condensation
- Cold windows
- Particularly important for retrofits


The "Perfect Wall" Finish of whatever Control continuity - Rain control layer · Perfect barrier Cladding · Drained with gap · Storage **Control layers** - Air control layer Structure · Air barrier Thermal control layer · Aka insulation, radiant barriers - Vapor control layer · Retarders, barriers, etc Structure can be anything Fire Control may be needed Sound Control optional Building Science.com 6






































Any R-value,	Brick veneer/stone veneer
e.g. 4" PIC=R25	Drained cavity
5"XPS =R25 6"MFI=R25	Exterior rigid insulation — extruded polystyrene, expanded polystyrene, isocyanurate, rock wool, fiberglass
	Membrane or trowel-on or spray applied vapor barrier (Class I vapor retarder), air barrier and drainage plane (impermeable)
	Concrete block
	Metal channel or wood furring
	Gypsum wall board (GWB)
	Latex paint or vapor semi-
	Vapor Profile





