

Joseph Lstiburek, Ph.D., P.Eng, ASHRAE Fellow

Building Science

Adventures In Building Science

presented by www.buildingscience.com

What is a Building?

A Building is an Environmental Separator

Thermodynamics

Zeroth Law – A=B and B=C therefore A=C

First Law - Conservation of Energy

Second Law - Entropy

Third Law – Absolute Zero

2nd Law of Thermodynamics

In an isolated system, a process can occur only if it increases the total entropy of the system

Rudolf Clausius

There Is No Such Thing As A Free Thermodynamic Lunch

Heat Flow Is From Warm To Cold
Moisture Flow Is From Warm To Cold
Moisture Flow Is From More To Less
Air Flow Is From A Higher Pressure to a
Lower Pressure
Gravity Acts Down

Moisture Flow Is From Warm To Cold
Moisture Flow Is From More To Less

Moisture Flow Is From Warm To Cold
Moisture Flow Is From More To Less

Thermal Gradient – Thermal Diffusion
Concentration Gradient – Molecular Diffusion

Moisture Flow Is From Warm To Cold
Moisture Flow Is From More To Less

Thermal Gradient – Thermal Diffusion
Concentration Gradient – Molecular Diffusion

Vapor Diffusion


Thermodynamic Potential

Carrier


PSYCHROMETRIC CHART

NORMAL TEMPERATURES

SI METRIC UNITS
Barometric Pressure 101.325 kPa
SEA LEVEL




Below 0°C Properties and Enthalpy Deviation Lines Are For Ice



Copyright ©Carrier Corporation 1975
Cat. No. 794-002 Printed in U.S.A.


Hygrothermal Analysis




Firmness, Commodity and Delight

“These are properly designed, when due regard is had to the country and climate in which they are erected. For the method of building which is suited to Egypt would be very improper in Spain, and that in use in Pontus would be absurd at Rome: so in other parts of the world a style suitable to one climate, would be very unsuitable to another”


Marcus Vitruvius Pollio (c.90-20 B.C.E.)








Map of DOE's Proposed Climate Zones




March 24, 2003


Los Angeles, CA




Minneapolis, MN




Lansing, MI



Las Vegas, NV



Seattle, WA



Arrhenius Equation

For Every 10 Degree K Rise
Activation Energy Doubles

$$k = A e^{-E_a/(RT)}$$

Damage Functions
Water
Heat
Ultra-violet Radiation

Microclimates and Materials Science











Environmental Loads
Rain Exposure Zone
Hygro-thermal Regions
Interior Climate Class






Water Control Layer



Air Control Layer

Vapor Control Layer


Thermal Control Layer




Wall




Slab





Roof





- ← **Ballast**
- ← **Filter fabric**
- ← **Control layers**
- ← **Roof structure**









































Configurations of the Perfect Wall













Commercial Enclosure: Simple Layers



- Structure
- Rain/Air/Vapor
- Insulation
- Finish










































































Water Management










































Intent of sealant is to limit this lateral flow of water between sheathing and building wrap

































































































Pascals mph


50 Pa =	20 mph
100 Pa =	30 mph
150 Pa =	35 mph
250 Pa =	45 mph
500 Pa =	65 mph
1,000 Pa =	90 mph


Wind Speed (mph) vs. Stagnation Pressure (Pa)

















Rain Screen




Beer Screen?










Vapor




Liquid


















Simple linearized energy-temperature relation for water
From Straube & Burnett, 2005










Figure 8-7. Outside vapour pressure, saturated vapour pressure and inside vapour pressure for Winnipeg.

