

Joseph Lstiburek, Ph.D., P.Eng, ASHRAE Fellow

Building Science

Adventures In Building Science

www.buildingscience.com

Physics

Physics....relax.....big words....but easy
concepts....

Arrhenius Equation

For Every 10 Degree K Rise
Activation Energy Doubles

$$k = Ae^{-E_a/(RT)}$$

Damage Functions

Water

Heat

Ultra-violet Radiation

Laws of Thermodynamics

Zeroth Law – Equal Systems

First Law - Conservation of Energy

Second Law - Entropy

Third Law – Absolute Zero

2nd Law of Thermodynamics

In an isolated system, a process can occur only if it increases the total entropy of the system

Rudolf Clausius

Heat Flow Is From Warm To Cold

Moisture Flow Is From Warm To Cold

Moisture Flow Is From More To Less

Air Flow Is From A Higher Pressure to a
Lower Pressure

Gravity Acts Down

Moisture Flow Is From Warm To Cold
Moisture Flow Is From More To Less

Moisture Flow Is From Warm To Cold
Moisture Flow Is From More To Less

Thermal Gradient – Thermal Diffusion
Concentration Gradient – Molecular Diffusion

Moisture Flow Is From Warm To Cold
Moisture Flow Is From More To Less

Thermal Gradient – Thermal Diffusion
Concentration Gradient – Molecular Diffusion

Vapor Diffusion

Thermodynamic Potential




PSYCHROMETRIC CHART

NORMAL TEMPERATURES

SI METRIC UNITS


Barometric Pressure 101.325 kPa

SEA LEVEL




Below 0°C Properties and Enthalpy Deviation Lines Are For Ice

Copyright ©Carrier Corporation 1975
Cat. No. 794-002 Printed in U.S.A.



DIFFUSION




**Higher Dewpoint Temperature
Higher Water Vapor Density
or Concentration
(Higher Vapor Pressure)
on Warm Side of Assembly**

**Low Dewpoint Temperature
Lower Water Vapor Density
or Concentration
(Lower Vapor Pressure)
on Cold Side of Assembly**






AIR TRANSPORT







**Higher Air
Pressure**


**Lower Air
Pressure**













90°F
50% RH



75°F
50% RH




60°F
50% RH




45°F
50% RH



30°F
50% RH








PSYCHROMETRIC CHART

NORMAL TEMPERATURES

SI METRIC UNITS

Barometric Pressure 101.325 kPa


SEA LEVEL



Copyright ©Carrier Corporation 1975
Cat. No. 794-002 Printed in U.S.A.

Example: Air leakage wetting of sheathing

Interior: 21 °C/40% RH
Exterior: -10 °C/85% RH
RSI 2.11 batt in studspace
RSI 1.40 insulated sheathing



Cooling and condensation


From Straube & Burnett, 2005

Water Molecules


Size Matters




Vapor




Liquid




Polar Molecule






Monolayers of adsorbed water increase with increasing RH




Monolayers
flow along surface
following concentration gradient









Calculating capillary rise



Capillary rise versus diameter





Surface area vs. particle size
From Straube & Burnett, 2005




Figure 1c. Gypsum, hydrated from plaster of paris and water, porosity 30 per cent.







Figure 1b. Brick, sintered clay, porosity 40 per cent.








Pressures

- Diffusion Vapor Pressure 3 to 5 psi
- Capillary Pressure 300 to 500 psi
- Osmosis Pressure 3,000 to 5,000 psi




Combined Flows



Ambient relative humidity at which capillary condensation is predicted to occur by the Kelvin equation


From Straube & Burnett, 2005



Change in the storage of moisture in a porous building material as the partial pressure of water vapor in the ambient air increases from zero to full saturation value at a given temperature.

Sorption Curve


From M.K. Kumaran, ASTM MNL 18-2nd Edition,
Moisture Control in Buildings, 2009



- A: Single-layer of adsorbed molecules
- B: Multiple layers of adsorbed molecules
- C: Interconnected layers (internal capillary condensation)
- D: Free water in Pores, capillary suction
- E: Supersaturated Regime


Regimes of moisture storage in a hygroscopic porous material


From Straube & Burnett, 2005



**Typical predicted sorption isotherm according to Kelvin equation
and modified BET theory**


From Straube & Burnett, 2005






Average sorption isotherm for wood as a function of temperature
 From Straube & Burnett, 2005

Moisture Content vs. Relative Humidity






Water Vapor Permeance vs. Relative Humidity




μ_1 = Dry cup permeance
 μ_2 = Wet cup permeance




Water Vapor Permeance of MemBrain™ Smart Vapor Retarder, Primed and Painted Gypsum Board, Unpainted Gypsum Board and Asphalt-Coated Kraft Paper




Water Vapor Permeance of WRB's






Water Vapor Permeance of Sheathing Materials





Vapor permeability test results for wood-based products as a function of RH
 [Kumaran *et al* 2002]
 From Straube & Burnett, 2005






Wood Fiber

Fibers get much thicker than longer when they pick up moisture

Studs get much wider and thicker, but not much longer, when they pick up moisture


Interesting Complications









































































Moisture Content vs. Relative Humidity







Plain



Hollow Back



Scratch Back



Hollow or Scratch Back



