


Joseph Lstiburek, Ph.D., P.Eng
John Straube, Ph.D., P.Eng

Building Science 2012

Thermal Control: Insulation & Thermal Bridges



presented by www.buildingscience.com

Why Control Heat flow?

1. Occupant Comfort
2. Control surface and interstitial condensation
3. Save energy, reduce operating cost & pollution
4. Save distribution & heating plant costs (capital)
5. Increase architectural options
6. Decrease load diversity
7. Meet codes and specs


Building Science

Insulation and Thermal Bridges No. 2/65

How to Control Heat Flow?

Modes of heat transfer:

- Radiation
- Convection
- Conduction



Building Science

Insulation and Thermal Bridges No. 3/65

Thermal Performance

- Thermal Conductivity
 - Symbol is "k" or " λ "
- Conductance
 - $C = k / \text{thickness}$
- Resistance "R-value"
 - $R = \text{thickness} / \text{conductivity}$
- Measures conduction only
- "effective" conductivity includes other modes

Building Science

Insulation and Thermal Bridges No. 5/65



Building Science 2008

Insulation and Thermal Bridges No. 6/65

R Values

- An effective property including all heat flow modes



Building Science

No. 7/65

Trends in materials


- Low density materials insulate better!
- High density materials are structural
- Past – relied on high density (but **thick**) structural materials to control heat, air, and moisture flow
 - Wood R 1.000 /inch
 - Clay Straw R 0.700 /inch
 - Old brick R 0.180 / inch
 - Concrete R 0.070 /inch
 - Steel R 0.004 / inch

Building Science 2008

Insulation and Thermal Bridges No. 12/65





Evolution - History



Building Science 2008

www.buildingscience.com





Changing Needs

- Now and tomorrow
 - Better heat flow control required
 - More environmental concerns re: energy
 - More demanding comfort standards
 - Building materials & finishes are less resistant to condensation (& mold)


Building Science 2008 Insulation and Thermal Bridges No. 22/65

Materials

- Thermal conductivity (& resistance) varies with
 - material type (conduction, radiation)
 - density and pore structure
 - moisture content
 - temperature difference
- Combination of insulation of air + material
- *Still* air is about R6/inch ($k=0.024 \text{ W/mK}$)
- Only gas fills (e.g. HCFC) can improve this

Building Science 2008

Insulation and Thermal Bridges No. 23/65



Building Science

Insulation and Thermal Bridges No. 24/65

Insulation

- A brief survey . . .

Building Science 2008

Insulation and Thermal Bridges No. 25/65

Fibers

- Mineral Fiber Insulation (vs organic fibers)
 - glass fiber
 - rock fiber } rockwool
 - slag fiber }
- Glass vs rockwool
 - melts at a much lower temperature
 - has thinner fibers so can use lower density
 - Lower density means more air permeance, less strength, and low volume (less cost and energy) shipping

Building Science

Insulation and Thermal Bridges No. 26/65

Blown/spray fibrous insulation

- Can use cellulose, glass, rockwool
- Net or adhesive holds sprayed fiber in cavity
- fills space and around obstructions
- avoids settling problems?
- May help control convection

- Are NOT vapour barriers

Building Science

Insulation and Thermal Bridges No. 27/65

Cellulose Wall Spray Insulation

- Density 2.5 to 4+ pcf (> 3pcf is recommended)
- R value 3.5 +/- depending on density
- Helps controls convection (higher density=better)
- Can fill irregular cavity spaces
- Settling a concern with low density (< 3pcf)
- Built in moisture concerns (MC? at close in)
- Provides moisture storage
- Controls mold with borate salts (avoid ammonia)
- Is not part of an air barrier system!

Building Science

Insulation and Thermal Bridges No. 28/65



Spray Foam

- Primarily polyurethane foam
 - open cell (CO₂ blown) e.g., Icynene
 - about R3.7/inch (R13/3.5", R20/5.5")
 - moderate to high vapour permeance (>10 perms)
 - Airtight <0.01 lps/m² @ 75 Pa
 - closed cell (gas blown)
 - R6+/inch
 - 1 - 2 US perms (don't need vapour barrier)
 - Airtight <0.01 lps/m² @ 75 Pa
- } Depends on skin

Building Science

Insulation and Thermal Bridges No. 31/65

Spray Foam

- Open cell
 - Most high vapor permeance
 - controls convection / wind washing
- Closed cell
 - air barrier and part vapor barrier
 - excellent air seal in difficult areas!
 - Beware: adhesion and movement/shrinkage cracks
- Both Expensive
- Neither solve air leakage outside of stud cavity

Building Science

Insulation and Thermal Bridges No. 32/65

Great for sealing/insulating difficult complex details






Building Science



- **Complete air-vapour-water barrier solution**
- **Requires transition membranes**

Building Science



Rigid Boards (sheathing)

- Expanded Polystyrene (EPS)
 - R-value of 3.6 to 4.2
- Extruded Polystyrene (XPS)
 - higher R-value, usually 5/inch or higher
 - usually more strength
- Polyisocyanurate (PIC)
 - Highest temp resistance. Long term R6
- all have fire “issues”

Building Science

Insulation and Thermal Bridges No. 39/65



Building Science

Insulation and Thermal Bridges No. 40/65



Mineral Fiber Sheathing

- Semi-rigid MFI (mineral fiber insulation)
- Rockwool and Fiberglass
 - Air permeable
 - Vapor permeable
 - Allows drainage (provides gap)
- R values of 4 to 4.4/inch

Building Science

Insulation and Thermal Bridges No. 42/65



Structural Insulated Panels

- Advantages
 - Superior blanket of insulation (3.5"=R12, 5.5"=R20)
 - if no voids then no convection or windwashing
 - May seal OSB joints for excellent air barrier system
- Therefore, done right = excellent
- Small air leaks at joints in roofs can cause problems
- Don't get them too wet from rain
 - Low perm layers means limited drying




Building Science

Insulation and Thermal Bridges No. 45/65



Insulated Concrete Forms


- Excellent enclosure system
- Concrete acts as air barrier
- No vapor barrier needed
- Expensive, but high performance (R20)

Building Science

Future products

- Vacuum panels: Depends on vacuum
 - R20-30/inch
 - VacuPor (Porextherm)
- Nanogel/aerogel
 - R12-20/inch
 - Aspen Aerogel



Building Science

Insulation and Thermal Bridges No. 48/65

Radiant barriers

- Often misunderstood
- Must have an air space!!! (below slabs?)
- Performance depends on temperature difference
 - better at high temperatures, e.g., roof, South
- Can be useful (R5 or so) if low cost
- Most effective at high temperatures (radiation $\propto T^4$)

How reflective is the material over time?
Are dust and corrosion avoided?

Building Science

Insulation and Thermal Bridges No. 49/65




There MUST be an airspace for radiant products to work




How much insulation?

- Regardless of type, use *more*
- Comfort & moisture –
 - True R5-10 is usually enough, but
- For energy / environment
 - As much as practical
- Practical constraints likely the limit
 - How much space available in studs?
 - Exterior sheathing of 1.5”/4”
- Increased insulation should reduce HVAC capital as well as operating!

Building Science

Insulation and Thermal Bridges No. 51/65



Building Science


Insulation and Thermal Bridges No. 52/65

But there are Complications

- Add up the R-values of the layers to get the total R-value of the assembly
- **BUT** the actual thermal resistance of an assembly is affected by
 - Air Leakage
 - Thermal Bridges
 - Thermal Mass

Building Science

Insulation and Thermal Bridges No. 53/65



Building Science

Insulation and Thermal Bridges No. 54/65


The Meaning of R-value

- Thermal Resistance
 - R-value (material property, not system)
 - Thermal Bridging
- Airtightness and Air Looping
 - About 10-40 % of energy loss
- Mass
 - smooths peaks and valleys
 - takes advantage of heat within (sun, equipment)
- Buildability / Inspectability
 - do you get what you spec/design?

Building Science

Insulation and Thermal Bridges No. 56/65

Internal Stack Effect & Insulation




Building Science

Insulation and Thermal Bridges No. 57/65

Internal Stack Effect

- Gaps in batt insulation on both sides
- closed circuit
- energy cost
- cold surfaces




Building Science

Insulation and Thermal Bridges No. 58/65



Steel studs provide conduits

- Hard to fill steel studs
- Results in gaps in batt insulation on both sides



Building Science 2008

Insulation and Thermal Bridges No. 60/65

It's More Than Insulation!

- Thermal bridges provide shortcut for heat through insulation
- Heat passes through the structural members
- Common offenders
 - Floor and balcony slabs
 - Shear walls
 - Window frames
 - Steel studs

Building Science

Insulation and Thermal Bridges No. 64/65



Building Science

Insulation and Thermal Bridges No. 66/65



Thermal Bridging

- Steel is 400 times more conductive than wood
- Steel studs are about 40 times thinner

Building Science

Insulation and Thermal Bridges No. 68/65

Wood vs Steel

Building Science





Insulation and Thermal Bridges No. 69/65

ASHRAE 90.1 "Clear Wall" best case

Insulation	R-11 3.5in	R-15 3.5in	R-19 6in	R-21 6in
ClearWall	8.4	10.0	12.9	13.8
Nominal	11	15	19	21

Building Science

Insulation and Thermal Bridges No. 70/65






Building Science

Insulation and Thermal Bridges No. 75/65

Thermal Bridging: Common Problems



Thermal Bridging Causes Surface Condensation



Building Science

Insulation and Thermal Bridges No. 76/65

Cold surfaces where $R < 5$



High RH / Low R



Insulation and Thermal Bridges No. 80/65

Thermal Bridge Examples

- Balcony, etc
- Exposed slab edge,






Solving Thermal Bridging



- Exterior insulation can solve most thermal bridges
 - Inside works, but hard to cover structural penetrations
- Lower interior RH to stop condensation

Building Science

Insulation and Thermal Bridges No. 82/65







Summary: Heat flow control

- A *continuous* layer of only R5-10 is key
 - Exterior is easiest to get continuous
 - Should provide much more for energy efficiency
- Heat flow control is not just about R-value!
 - Control of airflow
 - Thermal bridging must be managed
 - Thermal mass can play a role
 - Solar Gain can dominate
 - Window area, shading, low SHGC windows
 - Overhangs, light colors for walls and roofs